



ICY BOX®

Manual IB-2913MCL-C31

CloneStation & DockingStation for M.2 NVMe SSDs

Handbuch IB-2913MCL-C31

Klonstation & DockingStation für M.2 NVMe SSDs







Sicherheitshinweise

Zur Vermeidung körperlicher Schäden, sowie von Sach-, Geräteschäden und Datenverlust beachten Sie bitte folgende Hinweise:

Warnstufen

Signalwort und Sicherheitszeichen kennzeichnen die Warnstufe und geben einen sofortigen Hinweis auf Wahrscheinlichkeit, Art und Schwere der Folgen, wenn die Maßnahmen zur Vermeidung der Gefahr nicht befolgt werden.



GEFAHR

warnt vor einer **unmittelbar** gefährlichen Situation, die zum Tod oder zu schweren Verletzungen führen **wird**.



WARNUNG

warnt vor einer **möglicherweise** gefährlichen Situation, die zum Tod oder zu schweren Verletzungen führen **kann**.



VORSICHT

warnt vor einer **möglicherweise** gefährlichen Situation, die zu leichten Verletzungen führen **kann**.

ACHTUNG

warnt vor einer **möglichen** Situation, die zu Sach- und Umweltschäden führen und den Betriebsablauf stören **kann**.

1. Gefahren durch elektrische Spannung



WARNUNG

Kontakt mit elektrisch leitenden Teilen

Lebensgefahr durch Stromschlag

- vor Benutzung Betriebsanleitung lesen
- vor Arbeiten am Gerät, Spannungsfreiheit sicherstellen
- Kontaktschutzblenden nicht entfernen
- Kontakt mit Spannungsführenden Komponenten vermeiden.
- Steckkontakte nicht mit spitzen und metallischen Gegenständen berühren
- Verwendung nur in dafür vorgesehenen Umgebungen
- Gerät ausschließlich mit Typenschildkonformen Netzteil betreiben!
- Gerät/Netzteil fern von Feuchtigkeit, Flüssigkeit, Dampf und Staub halten
- Eigenständige Modifikationen sind unzulässig
- Gerät nicht während eines Gewitters anschließen
- Geben Sie Ihr Gerät im Reparaturfall in den Fachhandel

2. Gefahren während Montage (wenn vorgesehen)



VORSICHT

Scharfkantige Bauteile

Finger- oder Handverletzungen bei Zusammenbau (wenn vorgesehen) möglich

- vor Montage, Betriebsanleitung lesen
- Kontakt mit scharfen Kanten oder spitzen Bauteilen vermeiden
- Bauteile nicht mit Gewalt zusammensetzen
- geeignetes Werkzeug verwenden
- nur gegebenenfalls mitgeliefertes Zubehör und Werkzeug verwenden

3. Gefahren durch Wärmeentwicklung

ACHTUNG

Mangelhafte Belüftung des Geräts/Netzteils

Überhitzung und Ausfall des Geräts/Netzteils





Sicherheitshinweise

- externe Erwärmung vermeiden und Luftaustausch zulassen
- Lüfter-Auslass und passive Kühlkörper freihalten
- direkte Sonneneinstrahlung auf Gerät/Netzteil vermeiden
- ausreichend Umgebungsluft für Gerät/Netzteil sicherstellen
- keine Gegenstände auf dem Gerät/Netzteil abstellen

4. Gefahren durch Kleinstteile und Verpackung



WARNUNG

Erstickungsgefahr

Lebensgefahr durch Erstickern oder Verschlucken

- Kleinteile, Zubehör für Kinder unzugänglich verwahren
- Plastiktüten und Verpackung für Kinder unzugänglich verwahren/entsorgen
- Kleinteile und Verpackungen nicht in Kinderhände geben

5. Möglicher Datenverlust

ACHTUNG

Datenverlust bei Inbetriebnahme

Unwiederbringlicher Datenverlust möglich

- Unbedingt Hinweise in der Bedienungsanleitung/Schnellinstallationsanleitung beachten
- Produkt nur verwenden, wenn Spezifikationen erfüllt sind
- Datensicherung vor Inbetriebnahme durchführen
- Datensicherung vor Anschluss neuer Hardware durchführen
- dem Produkt beiliegendes Zubehör verwenden

6. Reinigung des Gerätes

ACHTUNG

Schädigende Reinigungsmittel

Kratzer, Farbveränderungen, Feuchteschäden oder Kurzschluss am Gerät

- vor Reinigung, das Gerät außer Betrieb nehmen
- aggressive bzw. scharfe Reinigungs- und Lösungsmittel sind ungeeignet
- nach der Reinigung sicherstellen, dass keine Restfeuchtigkeit vorhanden ist
- Reinigung der Geräte am besten mit trockenem Antistatiktuch durchführen

7. Entsorgung des Gerätes

ACHTUNG



Umweltverschmutzung, Wiederverwertung nicht möglich

Mögliche Umweltbelastung durch Bestandteile, Recyclingkreislauf unterbrochen

Dieses auf dem Produkt und der Verpackung angebrachte Symbol zeigt an, dass dieses Produkt nicht mit dem Hausmüll entsorgt werden darf. In Übereinstimmung mit der Richtlinie über Elektro- und Elektronik-Altgeräte (WEEE) darf dieses Elektrogerät und ggf. enthaltene Batterien nicht im normalen Hausmüll oder dem **Gelben Sack** entsorgt werden. Wenn Sie dieses Produkt und ggf. enthaltene Batterien entsorgen möchten, bringen Sie diese bitte zur Verkaufsstelle zurück oder zum Recycling-Sammelpunkt Ihrer Gemeinde.

Die enthaltenen Batterien müssen vor Rückgabe vollständig entladen sein. Treffen Sie Vorsorge, um die Batterien vor Kurzschluss zu schützen (z.B. durch das Isolieren der Kontaktpole mit Klebeband).

Bei Fragen kontaktieren Sie gerne unseren Support unter support@raidsonic.de oder besuchen Sie unsere Internetseite www.icybox.de.



Safety Information

Please read carefully the following information to prevent injuries, damage to material and device as well as data loss:

Warning levels

Signal words and safety codes indicate the warning level and provide immediate information in terms of the probability of occurrence as well as the type and severity of the consequences if the measures to prevent hazards are not complied with.



Warns of a **directly** hazardous situation causing **death or serious injury**.



Warns of a **potentially** hazardous situation that **may** cause death or serious injury.



Warns of a **potentially** hazardous situation that **may** cause minor injury.



Warns of a **potential** situation that **may** cause material or environmental damage and disrupt operative processes.

1. Risk of electrical shock



Contact with parts conducting electricity

Risk of death by electrical shock

- Read the operating instructions prior to use
- Make sure the device has been de-energised prior to working on it
- Do not remove contact protection panels
- Avoid contact with conducting parts
- Do not bring plug contacts in contact with pointed and metal objects
- Use in intended environments only
- Operate the device using a power unit meeting the specifications of the type plate only!
- Keep the device/power unit away from humidity, liquid, vapour and dust
- Do not modify the device
- Do not connect the device during thunderstorms
- Approach specialist retailers if you require repairs

2. Hazards during assembly (if intended)



Sharp components

Potential injuries to fingers or hands during assembly (if intended)

- Read the operating instructions prior to assembly
- Avoid coming into contact with sharp edges or pointed components
- Do not force components together
- Use suitable tools
- Use potentially enclosed accessories and tools only

3. Hazards caused by a development of heat



Insufficient device/power unit ventilation

Overheating and failure of the device/power unit

- Prevent externally heating up components and ensure an exchange of air



Safety Information

- Do not cover the fan outlet and passive cooling elements
- Avoid direct sunlight on the device/power unit
- Guarantee sufficient ambient air for the device/power unit
- Do not place objects on the device/power unit

4. Hazards caused by very small parts and packaging



WARNING

Risk of suffocation

Risk of death by suffocation or swallowing

- Keep small parts and accessories away from children
- Store/dispose of plastic bags and packaging in an area that is inaccessible to children
- Do not hand over small parts and packaging to children

5. Potential data loss

IMPORTANT

Data lost during commissioning

Potentially irreversible data loss

- Always comply with the information in the operating instructions/quick installation guide
- Exclusively use the product once the specifications have been met
- Back up data prior to commissioning
- Back up data prior to connecting new hardware
- Use accessories enclosed with the product

6. Cleaning the device

IMPORTANT

Harmful cleaning agents

Scratches, discolouration, damage caused by moisture or short circuit in the device

- Disconnect the device prior to cleaning
- Aggressive or intense cleaning agents and solvents are unsuitable
- Make sure there is no residual moisture after cleaning
- We recommend cleaning devices using a dry, anti-static cloth

7. Disposing of the device

IMPORTANT

Environmental pollution, unsuitable for recycling

Potential environmental pollution caused by components, recycling circle interrupted



This icon on product and packaging indicates that this product must not be disposed of as part of domestic waste. In compliance with the Waste Electrical and Electronic Equipment Directive (**WEEE**) this electrical device and potentially included batteries must not be disposed of in conventional, domestic waste or **recycling waste**. If you would like to dispose of this product and potentially included batteries, please return it to the retailer or your local waste disposal and recycling point.

The included batteries must be completely discharged before return. Take precaution to protect the batteries from short circuits (e.g. by insulating the contact poles with adhesive tape).

If you have any questions, please do not hesitate to contact our support at support@raidsonic.de or visit our website at www.icybox.de.



Manual IB-2913MCL-C31

Package content

1x IB-2913MCL-C31
1x USB cable
1x Power adapter
3x M.2 rubber fixation
1x Manual

System requirements

One free household EU 230 V power socket
One free USB Type-C® or Type-A port on your host computer
Supports M.2 PCIe NVMe SSD

Please note the following information about the compatibility of USB 3.2 Gen 2 enclosures and adapters, including this device!

The IB-2913MCL-C31 also works with computers and notebooks with USB 3.0/2.0/1.1 Type-C® or Type-A interfaces. The enclosure also works on devices with a Thunderbolt™ 3 or Thunderbolt™ 4 Type-C® interface with a transfer rate of up to 10 Gbit/s specified by USB 3.2 Gen 2.

Type-C® ports can be connected to USB 3.0 or 2.0 standard in some notebooks and computers. The enclosure only supplies the full data transfer rate of up to 10 Gbit/s with USB 3.2 Gen 2 equipped interfaces.

Overview


The IB-2913MCL-C31 is a Clone & Docking Station for M.2 PCIe NVMe SSDs. It is possible to create an exact copy of your M.2 SSD. The cloning process is done bit by bit. This enables to create a bootable copy of your M.2 SSD. The cloning process can be done without connecting to a computer. Only the connection to a power source is necessary.

In Docking Station mode, the IB-2913MCL-C31 can be used as a dual M.2 SSD enclosure. If two M.2 SSDs are installed and connected to the computer, both drives are displayed independently in the operating system and can be used as usual. With USB 3.2 Gen 2 a transfer rate of up to 10 Gbit/s can be achieved. With the USB combi cable, the IB-2913MCL-C31 can be connected to the computer with either USB Type-C® or USB Type-A.




Manual IB-2913MCL-C31

Front view




Top view





Manual IB-2913MCL-C31

Side view




1. 2x M.2 PCIe NVMe SSD 22x 30/42/60/80 mm
2. 2x rubber fixation for M.2 SSD

Key features

- Now clone M.2 SSDs quickly, easily and without tools
- Bootable M.2 SSD cloning even without PC (stand alone)
- M-Key socket for M.2 PCIe NVMe SSD
- SINGLE function: both M.2 SSDs are displayed independently
- Host connection via USB 3.2 Gen 2 Type-C® or Type-A
- High-performance with data transfer rates of up to 10 Gbit/s
- Active 40 mm fan keeps M.2 SSDs cool

SSD Installation


ATTENTION:
ONLY for **M.2 PCIe NVMe SSD!**
NOT for **M.2 SATA SSD!**






Manual IB-2913MCL-C31

1. Push and slide the lid to open the enclosure.




2. Gently insert the M.2 SSD in an angle of about 30° to the M.2 socket. Place the M.2 rubber fixation on the end at the semicircular notch of the M.2 SSD. Install target M.2 SSD to target port on the left side marked with "T". Install source M.2 SSD to source port on the right side marked with "S".






Manual IB-2913MCL-C31

3. Gently press down the M.2 SSD. Make sure that the M.2 rubber fixation is locked in place.



4. Slide the lid back onto the enclosure. Push until the lid clicks into place with haptic feedback.






Manual IB-2913MCL-C31

Usage

Clone mode

Important Information before you start the cloning process:

- **The target SSD (Target) must be of the same size or bigger than the source SSD (Source).**
- **If the target drive is smaller than the source drive, it is not possible to select the clone mode by pressing the button.**
- The clone function creates an identical copy of your drive – there is no need for a connection to any computer.
- Since the cloning process copies every single byte of the source drive, the process may take several hours depending on the drive capacity.
- After the cloning process is complete, the computer may not be able to identify both drives because they are assigned to the same drive letter. To separate the drives, at least one of the SSDs must be assigned a different drive letter or marked as "online". (Under Windows® it is „disk manager“).
- If only one drive is plugged into Source, there will be no action when you press the Clone button.
- If the target drive (Target) is bigger than the source drive (Source), you may create a new volume with the remaining space on the target drive after cloning.



DO NOT connect the IB-2913MCL-C31 **to computer** in clone mode.



LED description:






Manual IB-2913MCL-C31


1. As soon as the status LEDs TARGET and SOURCE light up continuously, press and hold the „clone“ button until a „beep“ sounds to start the cloning mode. As soon as all LEDs light up permanently, press the „clone“ button again to start the cloning process.




2. When the 25% LED and the LEDs of the source SSD and target SSD start flashing, the cloning process has started.
ATTENTION: DO NOT stop or turn off the device until the clone process is finished completely!



3. If all status LEDs for the cloning process flash at the same time, an error occurred as the target drive is smaller or one of the M.2 SSDs is damaged. Please turn off the device and change to a suitable or functional M.2 SSD.



4. When the cloning process is successfully completed, a „beep“ sounds and all LEDs light up continuously. Switch off the cloning station with the ON/OFF switch.




HINT: To uninstall the M.2 SSDs please make sure that the device is turned off.



Manual IB-2913MCL-C31

SINGLE mode



For SINGLE function as an external storage enclosure, connect the IB-2913MCL-C31 to a power outlet and a computer.

- The external SSDs can be connected to or disconnected from the computer without shutting down the computer.
- Please await the end of read/write operations before disconnecting the SSD to avoid data loss.
- A new SSD must first be initialized, partitioned and formatted by the operating system to be displayed by the system.
- If the drive is not recognised instantly by the operating system please check:
 - a) if the driver software is installed (USB)
 - b) if the SSD is initialized, partitioned and formatted.

Note: The full USB 3.2 Gen 2 transfer rate can only be achieved with a compatible USB 3.2 Gen 2 host computer. Furthermore, the USB 3.2 drivers must be installed by the operating system. If this is not the case, install the appropriate drivers for your operating system.



Handbuch IB-2913MCL-C31

Verpackungsinhalt

1x IB-2913MCL-C31
1x USB Kabel
1x Netzteil
3x M.2 Gummihalterung
1x Handbuch

Systemanforderungen

Eine freie haushaltsübliche EU 230 V Steckdose
Ein freier USB Type-C® oder Type-A Anschluss an Ihrem Hostcomputer
Unterstützt M.2 PCIe NVMe SSD

Bitte beachten Sie die folgenden Informationen zur Kompatibilität von USB 3.2 Gen 2 Gehäusen und Adaptern, einschließlich dieses Geräts!

Das IB-2913MCL-C31 funktioniert auch mit Computern und Notebooks mit USB 3.0/2.0/1.1 Type-C® oder Type-A Schnittstellen. Das Gehäuse funktioniert auch an Geräten mit einer Thunderbolt™ 3 oder Thunderbolt™ 4 Type-C® Schnittstelle mit einer Übertragungsrate von bis zu 10 Gbit/s, spezifiziert durch USB 3.2 Gen 2. Type-C® Anschlüsse können in einigen Notebooks und Computern mit dem USB 3.0 oder 2.0 Standard verbunden sein. Das Gehäuse liefert nur bei Schnittstellen, die mit USB 3.2 Gen 2 ausgestattet sind, die volle Datenübertragungsrate von bis zu 10 Gbit/s.


Überblick

Das IB-2913MCL-C31 ist eine Klon- & DockingStation für M.2 PCIe NVMe SSDs. Es ist möglich, eine exakte Kopie Ihrer M.2 SSD zu erstellen. Der Klonvorgang erfolgt Bit für Bit. So ist es möglich, eine bootfähige Kopie Ihrer SSD zu erstellen. Der Klonprozess kann ohne den Anschluss an einen Computer erfolgen. Es ist ausschließlich der Anschluss an eine Stromquelle nötig. Im DockingStation Modus kann die IB-2913MCL-C31 als zweifaches M.2 SSD Gehäuse genutzt werden. Sind zwei M.2 SSDs installiert und am Computer angeschlossen, werden beide Speichermedien unabhängig voneinander im Betriebssystem angezeigt und können wie gewohnt genutzt werden. Mit USB 3.2 Gen 2 stehen bis zu 10 Gbit/s zur Verfügung. Mit dem USB Kombi-Kabel kann die IB-2913MCL-C31 entweder mit USB Type-C® oder USB Type-A am Computer angeschlossen werden.




Handbuch IB-2913MCL-C31

Frontansicht




Draufsicht





Handbuch IB-2913MCL-C31

Seitenansicht



1. 2x M.2 PCIe NVMe SSD 22x 30/42/60/80 mm
2. 2x Gummihalterung für M.2 SSD


Hauptmerkmale

- Jetzt schnell, einfach und werkzeuglos M.2 SSDs klonen
- Bootfähige M.2 SSD klonen, auch ohne PC (stand alone)
- M-Key Sockel für M.2 PCIe NVMe SSD
- SINGLE Funktion: Beide M.2 SSDs werden einzeln angezeigt
- Hostanschluss über USB 3.2 Gen 2 Type-C® oder Type-A
- High-Performance mit Datenübertragungsraten von bis zu 10 Gbit/s
- Aktiver 40 mm Lüfter sorgt für Kühlung der M.2 SSDs

SSD Installation

ACHTUNG:


NUR für M.2 PCIe NVMe SSD!
NICHT für M.2 SATA SSD geeignet!






Handbuch IB-2913MCL-C31

1. Drücken und schieben Sie den Deckel zurück, um das Gehäuse zu öffnen.




2. Setzen Sie die M.2 SSD vorsichtig in einem Winkel von etwa 30° zum M.2 Sockel ein. Platzieren Sie die M.2 Gummihalterung am Ende an der halbrunden Kerbe der M.2 SSD.






Handbuch IB-2913MCL-C31

3. Drücken Sie die M.2 SSD vorsichtig nach unten. Vergewissern Sie sich, dass die M.2 Gummihalterung eingerastet ist.



4. Schieben Sie den Deckel wieder auf das Gehäuse. Drücken Sie, bis der Deckel mit einem haptischen Feedback einrastet.






Handbuch IB-2913MCL-C31

Anwendung

Klonmodus

Wichtige Informationen, bevor Sie den Klonvorgang starten:

- Die Ziel-SSD (Target) muss gleichgroß oder größer sein als die Quell-SSD (Source).
- Sollte die Ziel-SSD (Target) kleiner sein als die Quell-SSD (Source), so ist die Auswahl des Klon-Modus durch Drücken der Taste nicht möglich.
- Der Klon-Modus erstellt eine identische Kopie Ihrer SSD – ohne dass das Gerät an einen Computer angeschlossen werden muss.
- Da die Klonfunktion jedes einzelne Byte der Quell-SSD kopiert, kann dieser Vorgang abhängig von der Kapazität mehrere Stunden dauern.
- Nach Beendigung des Klonvorgangs kann es vorkommen, dass der Computer nicht beide Laufwerke identifizieren kann, da sie dem gleichen Laufwerksbuchstaben zugeordnet sind. Um dies zu beheben, muss mindestens einer der SSDs ein anderer Laufwerksbuchstabe zugewiesen oder als „online“ markiert werden (Windows®: Datenträgerverwaltung).
- Ist nur eine SSD in Source eingesetzt, kann der Klonvorgang durch Drücken der „clone“ Taste nicht begonnen werden.
- Sollte die Ziel-SSD (Target) größer sein als die Quell-SSD (Source), so bleibt nach dem Klonvorgang freie Kapazität für weitere Partitionen.



Verbinden Sie die IB-2913MCL-C31 im Klonmodus **NICHT** mit dem Computer.

LED Beschreibung:

Aus



An




Blinkend






Handbuch IB-2913MCL-C31

1. Sobald die Status LEDs TARGET und SOURCE dauerhaft leuchten, drücken und halten Sie die "clone" Taste bis ein „Piepton“ ertönt, um den Klonmodus zu starten. Sobald alle LEDs dauerhaft leuchten, drücken Sie die "clone" Taste erneut, um den Klonprozess zu starten.




Drücken und halten Sie die "clone" Taste




Drücken Sie die "clone" Taste erneut

2. Wenn die 25% LED und die LEDs von Quell-SSD und Ziel-SSD zu blinken beginnen, wurde der Klonprozess gestartet.


ACHTUNG: Schalten Sie das Gerät **NICHT** aus, bevor der Klonvorgang vollständig abgeschlossen ist!



3. Wenn alle Status LEDs für den Klonprozess gleichzeitig blinken, liegt ein Fehler vor, weil die Ziel-SSD zu klein ist oder eine der M.2 SSDs beschädigt ist. Bitte schalten Sie das Gerät aus und wechseln zu einer passenden oder funktionsfähigen M.2 SSD.



4. Wenn der Klonvorgang erfolgreich abgeschlossen ist, ertönt ein „Piepton“ und alle LEDs leuchten dauerhaft. Schalten Sie die Klonstation mit dem ON/OFF




Schalter aus.

Hinweis: Um die M.2-SSDs zu deinstallieren, stellen Sie bitte sicher, dass das Gerät ausgeschaltet ist.



Handbuch IB-2913MCL-C31

SINGLE Modus



Für die SINGLE Funktion als externes Gehäuse, schließen Sie das IB-2913MCL-C31 an eine Steckdose und einen Computer an.

- Die externen SSDs können an den Computer angeschlossen oder von ihm getrennt werden, ohne dass der Computer heruntergefahren werden muss.
- Bitte warten Sie das Ende der Lese-/Schreibvorgänge ab, bevor Sie die SSD abtrennen, um Datenverluste zu vermeiden.
- Eine neue SSD muss zunächst vom Betriebssystem initialisiert, partitioniert und formatiert werden, um vom System angezeigt zu werden.
- Wenn das Laufwerk nicht sofort vom Betriebssystem erkannt wird, prüfen Sie bitte:
 - o ob die Treibersoftware installiert ist (USB)
 - o ob die SSD initialisiert, partitioniert und formatiert ist.

Hinweis: Die volle USB 3.2 Gen 2 Übertragungsrate kann nur mit einem kompatiblen USB 3.2 Gen 2 Hostcomputer erreicht werden. Außerdem müssen die USB 3.2 Gen 2 Treiber vom Betriebssystem installiert werden. Sollte dies nicht der Fall sein, installieren Sie die entsprechenden Treiber für Ihr Betriebssystem.





Nos produits et emballages se recyclent, ne les jetez pas!
Trouvez où les déposer sur le site www.quefairedemesdechets.fr

© Copyright 2022 by RaidSonic Technology GmbH. All Rights Reserved

The information contained in this manual is believed to be accurate and reliable. RaidSonic Technology GmbH assumes no responsibility for any errors contained in this manual. RaidSonic Technology GmbH reserves the right to make changes in the specifications and/or design of the above mentioned product without prior notice. The diagrams contained in this manual may also not fully represent the product that you are using and are there for illustration purposes only. RaidSonic Technology GmbH assumes no responsibility for any differences between the product mentioned in this manual and the product you may have. Apple and macOS, MAC, iTunes and Macintosh are registered trademarks of Apple Computer Inc. Microsoft, Windows and the Windows logo are registered trademarks of Microsoft Corporation.

